LayLight₂
Automatic Coop Light

by **INCUBATOR WAREHOUSE**

Caution: This light is designed to be used inside a coop (or shed or other structure) and not outside where it will be exposed to the elements, such as rain and snow. The LayLight will handle chicken dust just fine, but it is not designed to get wet.

Included:

- Control Module
- LED Light
- Power Supply
- Adhesive Sticker
- Mounting Screws
  - 2 for Light
  - 2 for Controller

Installation

1. Determine the location of the light and controller.

   - Controller should be mounted within six feet of the LED light so the cord will reach

   - Controller should be placed in a location where it will be protected from rain and snow

   - LED Light should be placed in a location that will maximize the light in the coop

image 2

2. Use the two mounting screws to secure the control module to the coop wall. (image 2)

3. The front lens of the LED light unscrews to expose two mounting holes (image 3). Use the included mounting screws to secure the light. Twist the lens back into place.

   Note: The round adhesive sticker can be used to keep the LED light in place while mounting.

4. Plug the power supply into a power outlet. Ensure the power supply is protected from rain and other moisture.

5. Plug the light and power cord into the control module and the screen will light up. (image 4)

   Note: If you plug the power cord into the LayLight controller first and then plug in to the outlet, the controller may not recognize that it's getting power.

image 3

image 4

Programming

Press the "+" button to manually turn the light on. Press the "-" button to turn the light off.

Setup:

Press the "Enter" button for about 3 seconds to enter the programming mode. Press the "+" or "-" buttons to move through the menus.

There are five things to program.

1. Control Mode:

This allows you to set the light to perennial or seasonal. Perennial means that it will keep the same settings all year long. When you select perennial, whatever time settings you set will remain active year-round. Seasonal means that it will turn the light on and off during the winter months and keep it off during the summer months when there is more sunlight. When you select seasonal, you will set a start date and an end date. Once the end date has passed, the light will no longer turn on until the next season starts.

2. Timer 1:

Set the time in the morning that you want the light to come on. Then you'll select how long you want the light to stay on.

3. Timer 2:

Set the time in the evening that you want the light to come on. Then you'll select how long you want the light to stay on.

4. Date:

Set the current date. Month, date and year.

5. Time:

Set the current time. Select the hour, minute and AM/PM.

Battery: There is a cell-type battery inside the controller that will save the settings you have programmed, even if the unit is unplugged. If you find that when the controller is unplugged the settings are no longer saved, you will need to replace the battery (CR1225).

Questions or Comments

If you have any questions or comments about the LayLight2™ please either e-mail us at service@incubatorwarehouse.com or call us at (208)740-1344 and one of our customer service representatives will be happy to help.