

IncubatorWarehouse.com's Digital Hygrometer

INCUBATION TIPS

- Humidity Target= 35-55% up to 3 days before hatch, last 3 days increase to 60-80%
- For more information visit <http://incubatorwarehouse.com>

FEATURES

- Measures and displays relative humidity (measures humidity readings between 10-99% +/-5%)
- Very Compact 1.75" x 1.75" x 0.5" with LARGE easy to read LCD screen
- Battery INCLUDED (LR44)
- Backed by Incubator Warehouse's 1 Year Hassle Free Guarantee

USER INSTRUCTIONS

- Pull plastic tab to remove the battery insulator tab to engage battery

HYGROMETER PLACEMENT

- Make sure the hygrometer is NOT flat on the egg rack. When the egg turner is angled the hygrometer can slide in between the racks and jam the egg turner.
- When the display becomes faint or invisible, the battery needs to be replaced with a BRAND NEW battery
- Warranty is void if the unit has been opened or disassembled



service@incubatorwarehouse.com | 208-740-1EGG (1344)