

IncubatorWarehouse.com's IncuTherm™

Digital Thermometer Hygrometer with Min/Max Memory

INCUBATION TIPS


- ◆ Temperature Target = 99.5 (37.5 C) degrees Fahrenheit
- ◆ Humidity Target = 45-55% up to 3 days before hatch, last 3 days increase to 65-80%
- ◆ For more information visit <http://incubatorwarehouse.com/egg-incubator-information-center/>

FEATURES

- Measurement of HUMIDITY & TEMPERATURE
- Display shows humidity & temperature reading at the same time
- Measures and displays temperature in Celsius or Fahrenheit (switch on front)
- Measures and displays relative humidity (measures humidity readings between 10-99% +/-5%)
- Memory function to recall minimum and maximum humidity and temperature readings
- Very compact 2.5" x 2" x 0.5" with LARGE easy to read LCD screen
- Flip out stand for easy placement & 2 strong magnets for easy mounting (on back)
- Battery INCLUDED (3V CR2032)
- Backed by Incubator Warehouse's 1 Year Hassle Free Guarantee

USER INSTRUCTIONS

- Remove the battery cover in order to remove the black battery insulator tab to engage the battery
- C/F Button – Switches from Celsius to Fahrenheit Temperature Readings
- Memory Button – Displays the Maximum (MAX) and Minimum (MIN) temperature reading since the last time memory was cleared
- Clear Button – When in the MAX/MIN menus, pressing this button erases both the MAX & MIN values



THERMOMETER PLACEMENT

- Make sure the thermometer is NOT flat on the egg rack. When the egg turner is angled the thermometer can slide in between racks and jam the egg turner.



1. When the display becomes faint or invisible, the battery needs to be replaced with a BRAND NEW battery
2. Warranty is void if unit has been opened or disassembled



service@incubatorwarehouse.com | 208-561-2EGG (2344)